

COMMERCIAL ELECTRIC WATER HEATERS



INSTRUCTION MANUAL

MODELS SSL-20/ 30/ 40/ 50 LOW BOY UNITS
MODELS SSN-40/ 52/ 66/ 80/ 119 TALL UNITS

INSTALLATION | OPERATION | SERVICE |
MAINTENANCE | LIMITED WARRANTY



WARNING

Read and understand this instruction manual and the safety messages herein before installing, operating, or servicing this water heater.

Failure to follow these instructions and safety messages could result in death or serious injury.

This manual must remain with the water heater.

WARNING

If the water heater becomes immersed in water up to or above the level of the bottom of the element doors, the heater should be examined by a qualified service agency before it is placed in operation. See Page 2.



80-257 REV G_MANUAL_MODEL SSL,SSN



Conforms to UL1453
for Electric Commercial
Water Heaters.
Certified to CAN/ CSA
STD C22.2 No. 110-94

PLACE INSTRUCTIONS ADJACENT TO WATER HEATER & NOTIFY OWNER TO KEEP FOR FUTURE REFERENCE.

SAFE INSTALLATION, USE, AND SERVICE

The proper installation, use, and servicing of this water heater is extremely important to your safety and the safety of others.

Many safety-related messages and instructions have been provided in this manual and on your own water heater to warn you and others of a potential injury hazard. Read and obey all safety messages and instructions throughout this manual. It is very important that the meaning of each safety message is understood by you and others who install, use, or service this water heater.

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
 DANGER	DANGER indicates an imminently hazardous situation, which (if not avoided) could result in death or injury.
 WARNING	WARNING indicates a potentially hazardous situation, which (if not avoided) could result in death or injury.
 CAUTION	CAUTION indicates a potentially hazardous situation, which (if not avoided) could result in minor or moderate injury.
CAUTION	CAUTION used without the safety alert symbol indicates a potentially hazardous situation, which (if not avoided) could result in property damage.

All safety messages will generally tell you about the type of hazard, what can happen if you do not follow the safety message, and how to avoid the risk of injury.

IMPORTANT DEFINITIONS

Qualified Installer or Service Agency:

Installation and service of this water heater requires ability equivalent to that of a Qualified Agency (as defined by ANSI below) in the field involved. Installation skills such as plumbing and electrical are required in addition to electrical testing skills when performing service.

ANSI Z223.1 2006 Sec. 3.3.83:

Qualified Agency: “Any individual, firm, corporation, or company that either in person or through a representative is engaged in and is responsible for (a) the installation, testing, or replacement of gas piping or (b) the connection, installation, testing, repair, or servicing of appliances and equipment; that is experienced in such work; that is familiar with all precautions required; and that has complied with all the requirements of the authority having jurisdiction.”

GENERAL SAFETY INFORMATION

PRECAUTIONS

DO NOT USE THIS WATER HEATER IF ANY PART HAS BEEN EXPOSED TO FLOODING OR WATER DAMAGE. Immediately, call a qualified service technician to inspect the water heater and to replace any part of the control system that has been under water.

If the unit is exposed to the following, do not operate heater until all corrective steps have been made by a qualified service technician.


1. External Fire
2. Damage
3. Firing Without Water

GROUNDING INSTRUCTIONS

This water heater must be grounded in accordance with National Electrical Code and/ or local codes. These must be followed in all cases. Failure to ground this water heater properly may also cause erratic control system operation on ELECTRONIC CONTROL models.


This water heater must be connected to a grounded metal, permanent wiring system, or an equipment grounding conductor must be run with the circuit conductors and connected to the equipment grounding terminal or lead on the water heater.

HYDROGEN GAS (FLAMMABLE)

	 WARNING
	EXPLOSION HAZARD
	Flammable hydrogen gases may be present. Keep all ignition sources away from faucet when turning on hot water.


Hydrogen gas can be produced in a hot water system served by this heater that has not been used for a long period of time (generally two weeks or more). Hydrogen gas is extremely flammable. To reduce the risk of injury under these conditions, it is recommended that the hot water faucet be opened for several minutes at the kitchen sink before using any electrical appliance connected to the hot water system. If hydrogen is present, there will probably be an unusual sound, such as air escaping through the pipe as the water begins to flow. THERE SHOULD BE NO SMOKING OR OPEN FLAME NEAR THE FAUCET AT THE TIME IT IS OPEN.

When servicing this unit, verify the power to the unit is turned off prior to opening the control cabinet door.

	 WARNING
	EXPLOSION HAZARD
	Overheated water can cause water tank explosion. Properly sized temperature and pressure relief valve must be installed in opening provided.

	 WARNING
	Read and understand this instruction manual and the safety messages herein before installing, operating, or servicing this water heater.
	Failure to follow these instructions and safety messages could result in death or serious injury. This manual must remain with the heater.

	 WARNING
	Before removing any access panels or servicing the water heater, make sure the electrical supply to the water is turned OFF.
	Failure to do this could result in death, serious bodily injury, or property damage.

	 DANGER
	Water temperature over 125°F can cause severe burns, resulting in severe injury or death. Children, the elderly, and physically or mentally disabled are at highest risk for scald injury. Feel water before bathing or showering. Temperature limiting valves are available. Read instruction manual for safe temperature setting.

CAUTION
IMPROPER INSTALLATION, USE, AND SERVICE MAY RESULT IN PROPERTY DAMAGE
Do not operate water heater if any part has been exposed to flooding or water damage. Inspect anode rods regularly; replace when significantly depleted. Install in location with adequate drainage. Fill tank with water before operation. Properly sized thermal expansion tanks are required on all closed water systems. Refer to this manual for installation and service instructions.

TABLE OF CONTENTS

SAFETY INFORMATION	1 - 2
INTRODUCTION	3
DIMENSIONS & CAPACITIES DATA	4
APPROVALS	5
MODEL AND RATING	5
FEATURES & COMPONENTS	6
LOCATING THE WATER HEATER	7
INSTALLATION	7 - 9
ELECTRICAL	9 - 11
WIRING DIAGRAMS	10
OPERATION	12
TEMPERATURE REGULATION	13
MAINTENANCE	14
TROUBLESHOOTING	14 - 15
LEAKAGE CHECKPOINTS	15
REPLACEMENT PARTS	15 - 16
LIMITED WARRANTY	17

INTRODUCTION

Thank You for purchasing this water heater. Properly installed and maintained, it should give you years of trouble-free service.

Abbreviations found in this instruction manual include:

ANSI - American National Standards Institute
AHRI - Air Conditioning, Heating, and Refrigeration Institute.
NEC - National Electrical Code
NFPA - National Fire Protection Association
UL - Underwriter's Laboratory

PREPARING FOR THE INSTALLATION



WARNING

Before removing any access panels or servicing the water heater, make sure the electrical supply to the water is turned OFF.

Failure to do this could result in death, serious bodily injury, or property damage.

1. Read the "General Safety Information" section of this manual first, then read the rest of the manual carefully. If you don't follow the safety rules, the water heater may not operate safely. It could cause **DEATH, SERIOUS BODILY INJURY, AND/OR PROPERTY DAMAGE.**

This manual contains instructions for the installation, operation, and maintenance of the electric water heater. It also contains warnings throughout that must be read and understood. All warnings and all instructions are essential to the proper operation of the water heater and your safety. **READ THE ENTIRE MANUAL BEFORE ATTEMPTING TO INSTALL OR OPERATE THE WATER HEATER.**

Be sure to turn off all power when working on or near the electrical system of the heater. Never touch electrical components with wet hands or when

standing in water.

When replacing fuses, always use the correct size for the circuit.

The model and rating plates on page 5 interpret certain markings into useful information. Both of these references should be used to identify the heater, its components, and optional equipment.

2. The installation must conform with these instructions and the local code authority having jurisdiction and the requirements of the power company. In the absence of local codes, the installation must comply with the latest editions of the National Electrical Code, NFPA 70 or the Canadian Electrical Code CSA C22.1. The National Electrical Code may be ordered from :

National Fire Protection Association
1 Batterymarch Park
Quincy, MA 02269

The Canadian Electrical Code is available from:

Canadian Standards Association
8501 East Pleasant Valley Rd.
Cleveland OH, 44131

3. If after reading this manual you have any questions or do not understand any portion of the instructions, call the toll free number listed on the back cover of this manual for technical assistance.


A sample rating plate is shown on page 5. In order to expedite your request, please have full model and serial number available for the technician.

4. Carefully plan your intended placement of the water heater. Examine the location to ensure the water heater complies with the "Locating the Water Heater" section of this manual.

Installation and service of this water heater requires ability equivalent to that of a licensed tradesman or qualified agency (page 2) in the field involved. Plumbing and electrical work are required.

DIMENSIONS AND CAPACITIES DATA

ALL HOT OUTLETS AND COLD INLETS SUPPLIED WITH WATTS 3/4 LF301 DIELECTRIC UNION WITH 4" COPPER TUBE.



Model Number	Gallon Capacity	Maximum KW Input	No. of Elements	Height to Top	Diameter	Weight
Compact Models - Single Element						
SSL-20S	20	6.1	1	24.5	23.5	35lbs
Compact Models - Double Elements						
SSL-30D	30	12.2	2	34.0	23.5	75
SSL-40D	40	12.2	2	38.0	28.0	90
SSL-50D	50	12.2	2	40.0	28.0	105
Tall Models - Double Elements						
SSN-40D	40	12.2	2	44.0	23.5	90
SSN-52D	50	12.2	2	54.0	23.5	105
SSN-66D	60	12.2	2	48.0	28.0	140
SSN-80D	80	12.2	2	56.0	28.0	140
SSN-119D	119	12.2	2	74.0	28.0	175

Element Wattage (Upper/Lower)	KW In- put	US. Gallons/ HR. at Temperature Rise Indicated										
		36F	40F	54F	60F	72F	80F	90F	100F	108F	120F	126F
Non-Simultaneous Operation												
/1500	1.5	17	15	11	10	8	8	7	6	6	5	5
/2000	2.0	23	20	15	14	10	10	9	8	8	7	6
/2500	2.5	28	25	19	17	13	13	11	10	9	8	8
3000/3000	3.0	34	30	23	20	15	15	14	12	11	10	10
4000/4000	4.0	45	41	30	27	20	20	18	16	15	14	13
4500/4500	4.5	51	46	34	30	23	23	20	18	17	15	14
5000/5000	5.0	56	51	38	34	25	25	23	20	19	17	16
6000/6000	6.0	68	61	45	41	30	30	27	24	23	20	19
6100/6100	6.1	--	--	--	--	--	--	--	--	--	--	--
Simultaneous Operation												
3000/3000	6.0	68	61	45	41	34	30	27	24	23	20	19
4000/4000	8.0	90	81	60	54	45	41	36	32	30	27	26
4500/4500	9.0	101	91	68	61	51	46	41	36	34	30	29
5000/5000	10.0	113	101	45	67	56	51	45	41	37	34	32
6000/6000	12.0	135	122	90	81	67	61	54	49	45	41	39
6100/6100	12.2	140	126	93	84	70	63	56	50	47	42	40

DIMENSIONS & CAPACITIES

RECOVERY CAPACITIES

APPROVALS



Conforms to UL1453
for Electric Commercial
Water Heaters.
Certified to CAN/ CSA
STD C22.2 No. 110-94

MODEL AND RATING

LIGHT SERVICE COMMERCIAL ELECTRIC
STORAGE TANK WATER HEATER
Heat-flo, LLC.
UXBRIDGE, MA USA



Conforms to UL 1453
Certified to CSA STD
C22.2 #110
MASS Approval



MODEL NUMBER				SERIAL NUMBER	
VOLTS - AC	PHASE	WATTS UPPER	WATTS LOWER	RATED CAPACITY	WORKING PRESSURE (MAX PSI)
TOTAL WATTS CONNECTED					
CIRCUIT		SIMULTANEOUS 1 PH	INTERLOCK 1 PH	STANDBY LOSS % / HOUR	




SSL-20/ 30/ 40/ 50 & SSN-40/ 52/ 66/ 80/ 119


FEATURES AND COMPONENTS

ELECTRONIC CONTROL MODELS: Typical Water Heater Installations by Model Designation.


SSN/SSL DUAL-ELEMENT MODELS



SSN/SSL SINGLE-ELEMENT MODELS



INSTALL VACUUM RELIEF IN COLD WATER INLET LINE AS REQUIRED BY LOCAL CODES.



INSTALL THERMAL EXPANSION TANK IF CHECK VALVE OR PRESSURE-REDUCING VALVE IS USED IN SUPPLY LINE.



INSTALL SUITABLE DRAIN PANS UNDER WATER HEATERS TO PREVENT DAMAGE DUE TO LEAKAGE. REFER TO WATER HEATER LOCATION ON PAGE 7.

LOCATING THE WATER HEATER

FACTS TO CONSIDER ABOUT THE LOCATION

CAUTION

PROPERTY DAMAGE HAZARD

All water heaters eventually leak.
Do not install without adequate drainage.

The water heater should be located as close as possible to/or centralized to the water piping system. The water heater should be located in an area not subject to freezing temperatures.

The water heater should be located in an area where leakage of the tank or connections will not result in damage to the area adjacent to the heater or to lower floors of the structure.

Such pans should be at least two inches deep, have a minimum length and width of at least two inches greater than the diameter of the heater and should be piped to an adequate drain.

Water heater life depends upon water quality, water pressure, and the environment in which the water heater is installed. Water heaters are sometimes installed in locations where leakage may result in property damage, even with the use of a drain pan piped to a drain; however,

unanticipated damage can be reduced or prevented by a leak detector or water shut-off device used in conjunction with a piped drain pan. These devices are available from some plumbing supply wholesalers and retailers, and detect and react to leakage in various ways:

Sensors mounted in the drain pan that trigger an alarm or turn off the incoming water to the water heater when leakage is detected.

Sensors mounted in the drain pan that turn off the water supply to the entire home when water is detected in the drain pan.

Water supply shut-off devices that activate based on the water pressure differential between the cold water and hot water pipes connected to the water heater.

Devices that will turn off the gas supply to a gas water heater while at the same time shutting off its water supply.

CLEARANCES

A minimum clearance of 4" must be allowed for access to replaceable parts such as thermostats, drain valve, and relief valve.

Adequate clearance for servicing this water heater should be considered before installation, such as changing the anodes, etc...

INSTALLATION

REQUIRED ABILITY

Installation and service of this water heater requires ability equivalent to that of a qualified installer or service agency (page 2) in the field involved. Plumbing and electrical work is required.

GENERAL

The installation must conform with these instructions and the local code authority having jurisdiction and the requirements of the power company. In the absence of local codes, the installation must comply with the latest editions of the National Electrical Code, NFPA 70 or the Canadian Electrical Code CSA C22.1. The National Electrical Code may be ordered from:

National Fire Protection Association
1 Batterymarch Park,
Quincy, MA 02269


The Canadian Electrical Code is available from:

Canadian Standards Association
8501 East Pleasant Valley Rd.
Cleveland OH, 44131

DO NOT test electrical system before heater is filled with water. Follow the *START UP* procedure in the *OPERATION*

section of this manual.

The principle components of the heater are identified in the *Features and Components* illustration on page 6.

	! DANGER Water temperature over 125°F can cause severe burns, resulting in severe injury or death. Children, the elderly, and physically or mentally disabled are at highest risk for scald injury. Feel water before bathing or showering. Temperature limiting valves are available. Read instruction manual for safe temperature setting.
--	---

MIXING VALVE USAGE:

Water heaters are intended to produce hot water. Water heated to a temperature which will satisfy space heating, clothes-washing, dish-washing, cleaning, and other sanitizing needs can scald and permanently injure you upon contact. Some people are more likely to be permanently

INSTALLATION CONTINUED

injured by hot water than others. These include the elderly, children, the infirm, or physically/ developmentally disabled. If anyone using hot water in your home fits into one of these groups, or if there is a local code or state law requiring a maximum water temperature at the hot water tap, then you must take special precautions. In addition to using the lowest possible temperature setting that satisfies your hot water needs, a means such as a **MIXING VALVE** should be used at the hot water taps used by these people or at the water heater.

MIXING VALVES for reducing point of use temperature are available and are to be set at a maximum of 125°F. Consult a qualified installer or service agency. Follow all manufacturer's instructions for installation of these valves. Before changing the factory setting on the thermostat, read the *Temperature Regulation* section in this manual.



WARNING

TOXIC CHEMICAL HAZARD

Do not connect to non-potable water system.

CONTAMINATED WATER

This water heater shall not be connected to any heating system(s) used with a non-potable water heating appliance.

Toxic Chemicals, such as those used for boiler treatment, shall not be introduced into this system.

CIRCULATING PUMP

Field installed circulating pumps should be of all bronze or stainless steel construction.

INSULATION BLANKETS

Insulation blankets are available to the general public for external use on electric water heaters but are not necessary with this product. The purpose of an insulation blanket is to reduce the standby heat-loss encountered with storage tank heaters. Your water heater meets or exceeds the EPACT and ASHRAE/ IES 90.1 standards with respect to insulation and standby loss requirements, making an insulation blanket unnecessary.

Should you choose to apply an insulation blanket to this heater, you should follow these instructions below. Failure to follow these instructions can result in fire, serious personal injury, or death.

Do not cover the Temperature and Pressure (T&P) Valve with an insulation blanket.

Do not cover the instruction manual. Keep it on the side of the water heater or nearby for future reference.

Obtain new warning and instruction labels for placement on the blanket directly over the existing labels.



WARNING


EXPLOSION HAZARD

Temperature and Pressure Relief Valve must comply with ANSI Z21.22 and ASME code.

Properly-sized Temperature and Pressure Relief Valve must be installed in opening provided.

Failure to install relief valve can result in overheating and excessive tank pressure.

Failure to follow these instructions can cause serious injury or death.



TEMPERATURE AND PRESSURE RELIEF VALVE

This water heater is provided with a properly rated/ sized and certified combination Temperature and Pressure Relief Valve. The valve is certified by a nationally recognized testing laboratory that maintains periodic inspection of production of listed equipment of materials as meeting the requirements for Relief Valves for Hot Water Supply Systems, ANSI Z21.22 · CSA 4.4, and the code requirements of ASME.

If replaced, the new valve must meet the requirements of local codes, but not less than a combination Temperature and Pressure Relief Valve rated/ sized and certified as indicated in the above paragraph. The new valve must be marked with a maximum set pressure not to exceed the marked hydrostatic working pressure of the water heater (150 psi = 1,035 kPa) and a discharge capacity not less than the water heater BTU/ hr or KW input rate as shown on the water heater's model rating plate.

For safe operation of the water heater, the temperature and pressure relief valve must not be removed from its designated opening, nor plugged. The T&P Valve must be installed directly into the fitting of the water heater designated for the relief valve. Install the discharge piping so that any discharge will exit only within 6 inches above, or at any distance below, the structural floor. Be certain that no contact is made with any live electrical part. The use of more than four elbows can cause restriction and reduce the discharge capacity of the valve.

No valve or other obstruction is to be placed between the relief valve and the tank. Do not connect discharge piping directly to the drain unless a 6-inch air gap is provided. To prevent bodily injury, hazard to life, or property damage, the relief valve must be allowed to discharge water in adequate quantities should circumstances demand. If the discharge pipe is not connected to a drain or other suitable means, the water flow may cause property damage.

— **INSTALLATION CONTINUED ON NEXT PAGE** —

INSTALLATION CONTINUED

CAUTION

WATER DAMAGE HAZARD

Temperature and Pressure Relief Valve discharge pipe must terminate to an adequate drain.

The Discharge Pipe:

Shall not be smaller in size than the outlet pipe size of the valve or have any reducing couplings or other restrictions.

Shall not be plugged or blocked.

Shall be of material listed for hot water distribution.

Shall be installed so as to allow complete drainage of both the T&P Valve and the discharge pipe.

Must terminate at a maximum of 6 inches above a floor drain or external to the building. In cold climates, it is recommended that the discharge pipe be terminated at an adequate drain inside the building.

Shall not have any valve or other obstruction between the relief valve and the drain.

(1) no one is in front of or around the outlet of the T&P Valve discharge line, and

(2) the water manually discharged can cause bodily injury or property damage because the water may be extremely hot.

If after manually operating the T&P Valve it fails to completely reset and continues to release water, immediately close the cold water inlet to the water heater, follow the instructions in this manual, and replace the T&P Valve with a properly rated/ sized new one.

If you do not understand these instructions or have any questions regarding the T&P Valve, call the toll free number listed on the back cover of this manual for technical assistance.


CLOSED WATER SYSTEMS

Water supply systems may (because of code requirements or such conditions as high line pressure, among others) have installed devices such as pressure reducing valves, check valves, and back flow preventers. Devices such as these cause the water system to be a closed system.

THERMAL EXPANSION

As water is heated, it expands (thermal expansion). In a closed system, the volume of water will grow when it is heated. As the volume of the water grows, there will be a corresponding increase in water pressure due to thermal expansion. Thermal expansion can cause premature tank failure (leakage). This type of failure is not covered under the limited warranty. Thermal expansion can also cause intermittent T&P Valve operation: water discharged from the valve due to excessive pressure build-up. This condition is not covered under the limited warranty. The T&P Valve is not intended for the constant relief of thermal expansion.

A properly-sized thermal expansion tank should be installed on all closed systems to control the harmful effects of thermal expansion. Contact a local plumbing service agency to have a thermal expansion tank installed.

	⚠ DANGER Water temperature over 125°F can cause severe burns, resulting in severe injury or death. Children, the elderly, and physically or mentally disabled are at highest risk for scald injury. Feel water before bathing or showering. Temperature limiting valves are available. Read instruction manual for safe temperature setting.
---	---

The T&P Valve must be manually operated at least once a year. Caution should be taken to ensure that:

ELECTRICAL

	⚠ WARNING Before removing any access panels or servicing the water heater, make sure the electrical supply to the water heater is turned OFF. Failure to do this could result in death, serious bodily injury, or property damage.
--	--

GENERAL

The installation must conform with these instructions and the local code authority having jurisdiction, and the

requirements of the power company. In the absence of local codes, the installation must comply with the current editions of the National Electrical Code, NFPA 70 or the Canadian Electrical Code, CSA C22.1.

An electrical ground is required to reduce risk of electrical shock or possible electrocution. The water heater should be connected to a separate grounded branch circuit with over-current protection and disconnect switch. The water heater should be grounded in accordance with national and local codes.

Voltage applied to the heater should not vary more than +5% to -10% of the model rating plate marking for

ELECTRICAL CONTINUED

satisfactory operation.

DO NOT ENERGIZE THE BRANCH CIRCUIT FOR ANY REASON BEFORE THE HEATER TANK IS FILLED WITH WATER. DOING SO WILL CAUSE THE HEATING ELEMENTS TO BURN OUT AND VOID WARRANTY.

The factory wiring is attached to a terminal block within the junction box. The water heater should be connected to a separate, grounded branch circuit with over-current protection and disconnect switch. The water heater should be grounded in accordance with national and local codes.

BRANCH CIRCUIT

The branch circuit wire size should be established through reference to the current edition of NFPA-70, the National Electric Code or other locally approved source in conjunction with the heater amperage rating. For convenience, portions of the wire size tables from the Code are reproduced here. The branch circuit should be sized at 125% of the heater rating and further increase wire size as necessary to compensate for voltage drop in long runs.

CALCULATING AMPERAGE/OVER-CURRENT PROTECTION

The heaters come from the factory in 2 configurations:

1. Two-wire H-2 circuit for single-element heater equipped

with high-limit control and single phase power input.

2. Four-wire H-8 circuit for dual element heater equipped with two high-limit controls, single-phase, or three-phase power input.



The heater with dual elements is factory-wired for connection to a two-wire, single-phase delta branch circuit, simultaneous operation. In addition, a ground conductor is required.

Element connection is for simultaneous operation. This means both elements operate at the same time. The wiring diagram on page 10 shows the heater may be field-converted to Non-simultaneous element operation by moving the red wire on "L-1" terminal to J. It is then possible for both elements to operate separately as determined by the thermostats. Regardless of element connection, the heater operates in an "unbalanced" fashion.

The heater may be field-converted to single-phase operation by moving the wire on L-3 of the terminal block to L-2. L-3 is not used (see page 10).

The heater, now in single-phase non-simultaneous operation, may be field-converted to single-phase simultaneous operation by moving the red wire on terminal "J" to L-1 (see page 10).

WIRING DIAGRAMS



ELECTRICAL CONTINUED



WARNING

Before removing any access panels or servicing the water heater, make sure the electrical supply to the water is turned OFF.

Failure to do this could result in death, serious bodily injury, or property damage.

This is an example of calculating heater amperage for both types of element operation. From this, the branch circuit conductor and over-current protection sizing can be established.

The example is of a three-phase 240-volt unit with two 6 KW elements. The notations are for units field-converted to single-phase. Check the heater model and rating plate for actual specifications and substitute those values in the following:

TABLE 3

Non-Simultaneous (Factory-Wired)	Simultaneous (Field-Converted)
$3000 / 240 = 12.5 \text{ amps}^*$	$3000 / 240 = 12.5 \text{ amps}^*$ $12.5 \times 1.73 = 21.6 \text{ amps}$
*NOTE: As a single-phase non-simultaneous unit.	*NOTE: as a single-phase simultaneous unit the total is: $12.5 \times 2 = 25 \text{ amps}$

The rating of the over-current protection should be computed on the basis of 125% of the total connected load amperage. Where the standard rating and settings do not correspond with this computation, the next higher standard rating or setting should be selected.

Portion of Table 310-16 (NFPA-70) follows:

Allowable Ampacities of Insulated Copper Conductors

No more than three conductors in Raceway or Cable or Direct Burial (Based on Ambient Temperature of 86°F).

These ampacities relate only to conductors described in Table 310-13 in Code.

For ambient temperatures over 86°F, see Correction Factors (Note 13 in Code).

TABLE 4

Size	Temperature Rating of Conductor (See Table 310-13 in Code)	
AMG MCM	140°F	167°F
	Types: RUW, (14-2), T, TW, UF	Types: RH, RHW, RUH, (14-2), THW, THWN, XHHW, USE
18	---	---
16	---	---
14	15	15
12	20	20
10	30	30
8	40	45
6	55	65
4	70	85
3	80	100

Portion of Table 310-18 follows:

Allowable Ampacities of Insulated Aluminum and Copper - Clad Aluminum Conductors.

Not more than three conductors in Raceway or Cable or Direct Burial (based on Ambient Temperature of 86°F. These ampacities relate only to conductors described in Table 310-13 in Code.

For ambient Temperatures over 86°F, see correction Factors, Note 13 in Code.

TABLE 5

Size	Temperature Rating of Conductor (See Table 310-13 in Code)	
AMG MCM	140°F	167°F
	Types: RUW, (12-2), T, TW, UF	Types: RH, RHW, RUH, (12-2), THW, THWN, XHHW, USE
12	15	15
10	25	25
8	30	40
6	40	50
4	55	65
3	65	75
2	75	90
1	85	100

— OPERATION, NEXT PAGE —



OPERATION

GENERAL

Refer to the Features and Components section of this manual (page 6) for the location of components mentioned in the instructions that follow.

NEVER turn on power to the water heater without being certain the water heater is filled with water and a Temperature and Pressure Relief Valve is installed in the relief valve opening.

DO NOT TEST ELECTRICAL SYSTEM BEFORE HEATER IS FILLED WITH WATER. FOLLOW FILLING AND START-UP INSTRUCTIONS IN OPERATION SECTION.



FILLING THE WATER HEATER

1. Turn off the electrical disconnect switch.
2. Close the water heater drain valve.
3. Open a nearby hot water faucet to permit the air in the system to escape.
4. Fully open the cold water inlet pipe valve allowing the heater and piping to be filled.
5. Close the hot water faucet as water starts to flow. The heater is now ready for START-UP and TEMPERATURE REGULATION.

INITIAL START-UP

The following checks should be made by the installer when the heater is placed into operation for the first time.

1. Turn off the electrical disconnect switch.
2. Open the front panel or top access cover. Check all water and electrical connections for tightness. Also check connections on top and/or sides of heater. Repair water leaks and tighten electrical connections as necessary.
3. Depress the red manual reset button on each Thermostat/ECO combination control. (See Figure 5, 6, 7, or, 8).
4. Turn on the electrical disconnect switch.

5. Observe the operation of the electrical components during the first heating cycle. Use care as the electrical circuits are energized.

6. Close the front panel or top access cover.


Temperature control and contactor operation should be checked by allowing heater to come up to temperature and shut off automatically. Use care as the electrical circuits are energized.

DRAINING THE WATER HEATER


The water heater must be drained if it is to be shut down and exposed to freezing temperatures. Maintenance and service procedures may also require draining the heater.

1. Turn off the electrical disconnect switch.
2. Open the hot water valve until the water is cool, then close the supply water inlet valve to the heater.
3. Attach hose to outlet opening of the drain valve and direct end to drain.
4. Open a nearby hot water faucet and the heater drain valve.
5. If the heater is being drained for an extended shutdown, it is suggested the drain valve be left open during this period. The hose may be removed.

Follow the *FILLING* instructions when restoring hot water service.



TEMPERATURE REGULATION



⚠ DANGER

Water temperature over 125°F can cause severe burns, resulting in severe injury or death.

Children, the elderly, and physically or mentally disabled are at highest risk for scald injury.

Feel water before bathing or showering.

Temperature limiting valves are available.

Read instruction manual for safe temperature setting.

THE WATER HEATER IS EQUIPPED WITH AN ADJUSTABLE THERMOSTAT TO CONTROL WATER TEMPERATURE. HOT WATER AT TEMPERATURES DESIRED FOR AUTOMATIC DISHWASHER AND LAUNDRY USE CAN CAUSE SCALDS, RESULTING IN SERIOUS PERSONAL INJURY AND/OR DEATH. THE TEMPERATURE AT WHICH INJURY OCCURS VARIES WITH THE PERSON'S AGE AND TIME OF EXPOSURE. THE SLOWER RESPONSE TIME OF CHILDREN, AGED, OR DISABLED PERSONS INCREASES THE HAZARD TO THEM. NEVER ALLOW SMALL CHILDREN TO USE A HOT WATER TAP OR TO DRAW THEIR OWN BATH WATER. NEVER LEAVE A CHILD OR DISABLE PERSON UNATTENDED IN A BATHTUB OR SHOWER.

It is recommended that lower water temperatures be used to avoid the risk of scalding. It is further recommended, in all cases, that the water temperature thermostats (see Table 6) be set for the lowest temperature, which satisfies your hot water needs. This will also provide the most energy efficient operation of the water heater.

Table 6 shows the approximate time-to-burn relationship for normal adult skin. The thermostats on your water heater have a linear relationship between degrees of angular rotation and the corresponding change in temperature. Thus, rotating the temperature adjustment indicator 30 angular degrees will result in a 10°F change in water temperature.

TABLE 6

Water Temperature	Time to produce 2nd & 3rd Degree Burns on Adult Skin
181°F	INSTANTANEOUS
160°F	ABOUT 1/2 SECOND
150°F	ABOUT 1-1/2 SECONDS
140°F	LESS THAN 5 SECONDS
130°F	ABOUT 30 SECONDS
120°F	MORE THAN 5 MINUTES

TEMPERATURE ADJUSTMENT

The water heater is supplied with thermostats that may come from different manufacturers and have different temperature indications as described next:

APCOM THERMOSTATS

H-8 circuit thermostats have three designated set points: LO, MED, and HI (see Figure 5). The approximate equivalent temperatures for these three settings are:

LO = 140°F
MED = 160°F
HI = 170°F

These thermostats are set from the factory at the LO setting. The over temperature device (ECO High-Limit) attached to each thermostat has a manual reset. The over-temperature device (ECO High-Limit) attached to each thermostat has a manual reset.

FIGURE 5





FIGURE 6




NOTE: It is not necessary to adjust the upper thermostat for a dual-element unit; however, if it is adjusted above the factory set-point of 125°F, it is recommended that it not be set higher than the lower thermostat setting.

To change the temperature setting:

1. **DANGER:** Turn off the heater electrical supply. Do not attempt to adjust the thermostat with power on.
2. Open the junction box door (for upper thermostat of dual-element water heater only) and/or remove the (lower) thermostat access panel. Do not remove the plastic personnel protectors covering the thermostats. The thermostat is factory pre-set at 125°F.
3. Using a flat-head screwdriver, rotate the adjusting knob to the desired temperature setting.
4. Replace the covers and access panels, and turn on the heater electrical supply.

MAINTENANCE



GENERAL

Periodically, the drain valve should be opened and the water allowed to run until it flows clean. This will help to prevent sediment buildup in the tank bottom.

Periodically, check the Temperature and Pressure Relief Valve to ensure that it is in operating condition. Lift the lever at the top of the valve several times until the valve seats properly and operates freely.


Water heater maintenance includes periodic tank flushing and cleaning, and removal of lime scale from the heating element.

TROUBLESHOOTING CHECKLIST

CHECKLIST

Before calling for service, check the following points to see if cause of trouble can be identified and corrected.

Reviewing this checklist may eliminate the need of a service call and quickly restore hot water service. See page 6 in this manual to identify and locate water heater components.



NOT ENOUGH OR NO HOT WATER

1. Be certain the electrical disconnect switch serving the water heater is in the ON position.

2. Check the fuses.

- The electrical disconnect switch usually contains fuses.
3. If the water was excessively hot and is now cold, the high limit switch may have activated.
- Large demands require a recovery period to restore water temperature.

4. The capacity of the heater may have been exceeded by a large demand for hot water.

5. Cooler incoming water temperature will lengthen the time required to heat water to the desired temperature.

6. Look for hot water leakage.

7. Sediment or pipe scale may be affecting water heater operation.

ABNORMAL SOUNDS

1. Sediment or lime scale accumulations on the elements causes sizzling and hissing noises when the heater is operating.

— TROUBLESHOOTING/ LEAKING, NEXT PAGE —

TROUBLESHOOTING CHECKLIST, CONTINUED

WATER LEAKAGE IS SUSPECTED

Refer to Leakage Checkpoint (next section).

1. Check to see if the heater drain valve is tightly closed.
2. If the outlet of the relief valve is leaking, it may be due to one or more of the following:

Excessive water temperature
Faulty relief valve
Excessive water pressure

3. Excessive water pressure is the most common cause of relief valve leakage. It is often caused by a "closed system." See *Closed Water Systems* and *Thermal Expansion* in the "Installation" section of this manual.

4. Examine the area around the element for gasket leakage.

Tighten the elements, or (if necessary) follow the

WATER AND LIME SCALE REMOVAL procedure to replace the gaskets.

IF UNABLE TO IDENTIFY OR CORRECT THE SOURCE OF MALFUNCTION

1. Turn the power supply to the water heater off.
2. Close the supply water inlet valve to the heater.
3. Contact a Qualified Service Agency in your area. Call the toll free phone number on the back cover of this Instruction Manual for assistance in locating a service agency in your area.

REPLACEMENT PARTS


Call the phone number on the back cover of this Instruction Manual for assistance in locating replacement parts. When ordering parts, specify complete model no. (see rating plate), quantity, and name of the part desired. Standard hardware items should be purchased locally.

LEAKAGE CHECKPOINTS

Num.	Part Name	Leakage Point(s)
1	T&P Valve	Leak from Plumbing Connection Point/ Leak from Weld to Outer Tube/ Leak from Weld to Tank Head
2*	1 7/16" - 14 Male Nipple	Leak from Plumbing Connection Point/ Leak from Weld to Outer Tube/ Leak from Weld to Tank Head
5	Elec. Element Flange	Leak from Weld to Tank Shell
7	Drain Valve	Leak from Valve/ Leak at Connection Point/ Leak from Weld to Tank Shell

REPLACEMENT PARTS

Num.	Part Name	Item Number
1	T&P Valve	VALVE-TP-WATTS-100XL8
3	Thermostat	ELEC_THERMOSTAT
4	Heating Element	*SEE TABLE 7 ON NEXT PAGE FOR OPTIONS
5	Thermostat Bracket	ELEC_THERM. BRACKET
6	Drain Valve	VALVE_DRAIN



*Fits Watts 3/4 LF301 Dielectric Union (included with unit).

REPLACEMENT HEATING ELEMENTS

TABLE 7

VOLTAGE	TOTAL KW INPUT	ELEMENT WATTAGE	PART NUMBER
120	1.5	1500	ELEC_EL-120V1500W
	2.0	2000	ELEC_EL-120V2000W
	2.5	2500	ELEC_EL-120V2500W
	3.0	3000	ELEC_EL-120V3000W
277	1.5	1500	ELEC_EL-277V1500W
	2.0	2000	ELEC_EL-277V2000W
	2.5	2500	ELEC_EL-277V2500W
	3.0	3000	ELEC_EL-277V3000W
	4.5	4500	ELEC_EL-277V4500W
	6.1	6100	ELEC_EL-277V6100W
208	1.5	1500	ELEC_EL-208V1500W
	2.0	2000	ELEC_EL-208V2000W
	2.5	2500	ELEC_EL-208V2500W
	3.0	3000	ELEC_EL-208V3000W
	4.5	4500	ELEC_EL-208V4500W
	5.0	5000	ELEC_EL-208V5000W
	5.5	5500	ELEC_EL-208V5500W
	6.1	6100	ELEC_EL-208V6100W
240	1.5	1500	ELEC_EL-240V1500W
	2.0	2000	ELEC_EL-240V2000W
	2.5	2500	ELEC_EL-240V2500W
	3.0	3000	ELEC_EL-240V3000W
	4.5	4500	ELEC_EL-240V4500W
	5.0	5000	ELEC_EL-240V5000W
	5.5	5500	ELEC_EL-240V5500W
	6.1	6100	ELEC_EL-240V6100W
480	2.5	2500	ELEC_EL-480V2500W
	3.0	3000	ELEC_EL-480V3000W
	4.5	4500	ELEC_EL-480V4500W
	5.0	5000	ELEC_EL-480V5000W
	6.1	6100	ELEC_EL-480V6100W

ELEMENTS AVAILABLE PER UNIT

SSN/SSL	Guide for Elements in Electric Tanks Based on Model																						
Model #	United States																						
	Input (kW) per Element - Single Element											Input (kW) per Element - Dual Element											
	1.5	2.0	2.5	3.0	3.5	4.0	4.5	5.0	5.5	6.0	6.1	1.5	2.0	2.5	3.0	3.5	4.0	4.5	5.0	5.5	6.0	6.1	
SSL-20S	----	----	X	X	X	X	X	X	X	X	X	----	----	----	----	----	----	----	----	----	----	----	
SSL-30D	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	
SSL-40D	----	----	----	----	----	----	X	X	X	X	X	----	----	----	X	X	X	X	X	X	X	---	
SSL-50D	----	----	----	----	X	X	X	X	X	X	X	----	----	----	X	X	X	X	X	X	X	X	
SSN-40D	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	X	
SSN-52D	----	----	----	X	X	X	X	X	X	X	X	----	----	----	X	X	X	X	X	X	X	X	

Key	
Available	X
Unavailable	---



COMMERCIAL ELECTRIC WATER HEATER LIMITED WARRANTY

EFFECTIVE

For 3 Years, in the event of a tank leak, we will repair or, at our discretion, replace the defective water heater. For 1 Year, in the event of part failure, we will repair or, at our discretion, replace the defective part. We warrant this product against defects in materials or workmanship as described in this document if installed within the United States or Canada and provided the product remains at its original place of installation. Warranty coverage begins the date of installation OR the date of manufacture if installation cannot be verified.

WHAT IS COVERED

Subject to these terms, in the event of defect in materials and/or workmanship resulting in a tank leak during the first three years, we will: Replace the water heater should the tank leak. Subject to these terms, in the event of a defect in materials and/or workmanship appearing during the first year, we will: Repair or, at our discretion, replace any part of the water heater covered under this limited warranty excluding parts subject to normal maintenance (Example: anode rod, filter, etc...).

WHAT IS NOT COVERED

- Problems caused by improper: Voltage, wiring, fusing
- Failure to follow applicable codes
- Failure to follow printed instructions
- Abuse, misuse, accident, fire, flood, Acts of God
- Improper installation, sizing, delivery, or maintenance
- Claims related to rust, noise, smell, or taste of water
- Failure to conduct authorized factory start up if required
- Alterations to the water heater
- Non-outdoor heaters installed outdoors
- Damages due to a failure to allow for thermal expansion
- Heat-exchanger failure due to lack of adequate/ proper supply of water
- Heaters moved from their original location
- Service trips to explain proper installation, use, or maintenance of the product/unit or to describe compliance requirements under applicable codes and regulations
- Charges related to accessing your heater including, but not limited to: Door/wall removal, equipment rental, etc...
- Replacement parts after expiration of this warranty

LIMITATION

NOTWITHSTANDING ANYTHING ELSE TO THE CONTRARY, THIS IS YOUR SOLE AND EXCLUSIVE WARRANTY. ALL OTHER WARRANTIES, INCLUDING A WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, ARE EXPRESSLY DISCLAIMED. SELLER SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL, PUNITIVE, OR OTHER INDIRECT DAMAGES. TOTAL LIABILITY ARISING AT ANY TIME SHALL NOT EXCEED THE PURCHASE PRICE PAID, WHETHER BASED ON CONTRACT, TORT, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY.


SERVICES INQUIRIES:

For service inquiries, call the telephone number listed below. Be prepared to provide the following information: Name, address, and telephone number; the model and serial number of the water heater; proof of installation; and a clear description of the problem.

For your records, fill in the product:

Serial: _____
Model: _____

Heat-flo, LLC., 15 Megan Ct., P.O. Box 612, Uxbridge, MA 01569 USA
Tel: 508-278-2400 | Fax: 508-278-2466 | www.heat-flo.com



Heat-flo

Heat-flo, LLC.

P.O. BOX 612
UXBRIDGE, MA 01569

508-278-2400

www.heat-flo.com